

INSTRUCTION MANUAL

FLEXCUT[®] PRO FLEXCONNECT



**For use with Product/Code
Numbers:**

**KP5850-25, KP5852-25,
KP5850-50, KP5852-50**

Save for future reference

Date Purchased

Code: (ex: 10859)

Serial: (ex: U1060512345)



ISO OERLIKON AG Schweisstechnik

CH-5737 Menziken AG – Tel. +41 (0)62 771 83 05

E-Mail info@iso-oerlikon.ch – www.iso-oerlikon.ch

Contents

INSTALLATION..... SECTION A

GENERAL DESCRIPTION.....A-1

TECHNICAL SPECIFICATIONS A-1

SELECT PROPER SETUP..... A-1

ENVIRONMENTAL LIMITATIONS..... A-1

OUTPUT CONNECTIONS.....A-2

OPERATION..... SECTION B

PREHEAT..... B-1

USER RESPONSIBILITY..... B-2

DESIGN FEATURES AND ADVANTAGES..... B-2

LIMITATIONS..... B-2

CONTROLS AND SETTINGS..... B-3

TORCH HEAD REPLACEMENT AND OPTIONS..... B-3

HAND CUTTING TORCH PART CONFIGURATIONS..... B-5

GOUGING PROCESS..... B-7

MECHANIZED CUTTING..... B-8

CONSUMABLE LIFE..... B-11

CUTTING CAPABILITY..... B-11

ACCESSORIES AND OPTIONS..... SECTION C

ACCESSORIES AND OPTIONS..... C-1

MAINTENANCE..... SECTION D

CUT QUALITY..... D-1

TROUBLESHOOTING..... SECTION E

HOW TO USE TROUBLESHOOTING GUIDE..... E-1

TROUBLESHOOTING CHART..... E-2

CUSTOMER ASSISTANCE POLICY

SAFETY INFORMATION

SAFETY DEPENDS ON YOU

Lincoln welding, cutting, and heating equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation and thoughtful operation on your part. **DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.** And, most importantly, think before you act and be careful.

DANGER



This statement indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING



This statement indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION




This statement indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.

Notice: This statement indicates the possibility of damage to equipment if the potential risk is not avoided.

PLEASE EXAMINE CARTON AND EQUIPMENT FOR DAMAGE IMMEDIATELY

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

KEEP YOUR HEAD OUT OF THE FUMES



- **DON'T** get too close to the weld. Use corrective lenses if necessary to stay a reasonable distance away from the weld.
- **USE ENOUGH VENTILATION** or exhaust at the weld, or both, to keep the fumes and gases from your breathing zone and the general area.
- **IN A LARGE ROOM OR OUTDOORS**, natural ventilation may be adequate if you keep your head out of the fumes.
- **USE NATURAL DRAFTS** or fans to keep the fumes away from your face.
- **READ** and obey the Safety Data Sheet (SDS) and the warning label that appears on all containers of welding materials.

If you develop unusual symptoms, see your supervisor. Perhaps the welding atmosphere and ventilation system should be checked.

WEAR CORRECT EYE, EAR AND BODY PROTECTION



- **PROTECT** your eyes and face with properly fitted and with proper grade of filter plate (See ANSI Z49.1).
- **PROTECT** your body from welding spatter and arc flash with protective clothing including woolen clothing, flame-proof apron and gloves, leather leggings, and high boots.
- **PROTECT** others from spatter, flash, and glare with protective screens or barriers.
- **PROTECT** your eyes and face with welding helmet
- **IN SOME AREAS**, protection from noise may be appropriate.
- **BE SURE** protective equipment is in good condition.
- **AT ALL TIMES**, wear safety glasses in work area.
- **DO NOT WELD, CUT, OR HEAT** containers or materials which previously had been in contact with hazardous substances unless they are properly cleaned. This is extremely dangerous.



SAFETY INFORMATION

- **DO NOT WELD, CUT, OR HEAT** painted or plated parts unless special precautions with ventilation have been taken. They can release highly toxic fumes or gases.
- **PROTECT** compressed gas cylinders from excessive heat, mechanical shocks, and arcs; fasten cylinders so they cannot fall.
- **BE SURE** cylinders are never grounded or part of an electrical circuit.
- **REMOVE** all potential fire hazards from welding area.



- **ALWAYS HAVE FIRE FIGHTING EQUIPMENT READY FOR IMMEDIATE USE AND KNOW HOW TO USE IT.**

CALIFORNIA PROPOSITION 65 WARNINGS

WARNING



Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects, or other reproductive harm.

Always start and operate the engine in a well-ventilated area.

If in an exposed area, vent the exhaust to the outside.

Do not modify or tamper with the exhaust system.

Do not idle the engine except as necessary.

WARNING



This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code § 25249.5 et seq.)

For more information go to <https://www.p65warnings.ca.gov>

ARC WELDING CAN BE HAZARDOUS

PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.

FOR ENGINE POWERED EQUIPMENT



- Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.
- Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.
- Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.



- In some cases it may be necessary to remove safety guards to perform required maintenance. **REMOVE GUARDS ONLY** when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.
- **DO NOT** put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.



- To avoid scalding, do not remove the radiator pressure cap when the engine is hot.
- Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.
- Using a generator indoors **CAN KILL YOU IN MINUTES**.
- **NEVER** use inside a home or garage, EVEN IF doors and windows are open.
- **ONLY** use **OUTSIDE** and far away from windows, doors and vents.



- Avoid other generator hazards. **READ MANUAL BEFORE USE.**

ELECTRIC AND MAGNETIC FIELDS MAY BE DANGEROUS



- Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding and heating current creates EMF fields around cables and equipment.
- EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- Exposure to EMF fields in welding may have other health effects which are now not known. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
- Route the electrode and work cables together - Secure them with tape when possible.

- Never coil the electrode lead around your body.
- Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
- Connect the work cable to the workpiece as close as possible to the area being welded.
- Do not work next to welding power source.

ELECTRIC SHOCK CAN KILL



- The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
- DC Manual (Stick) Welder.
- AC Welder with Reduced Voltage Control.
- In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".
- Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- Ground the work or metal to be welded to a good electrical (earth) ground.
- Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- Never dip the electrode in water for cooling.

SAFETY INFORMATION

- Never simultaneously touch electrically “hot” parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
- **Also see [WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION](#) and [FOR ELECTRICALLY POWERED EQUIPMENT](#)**

ARC RAYS CAN BURN



- Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87.1 standards.
- Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.

FUMES AND GASES CAN BE DANGEROUS



Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone.

- **When welding hardfacing (see instructions on container or SDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation unless exposure assessments indicate otherwise. In confined spaces or in some circumstances, outdoors, a respirator may**

also be required. Additional precautions are also required when welding on galvanized steel.

- The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- Shielding gases used for welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the Safety Data Sheet (SDS) and follow your employer's safety practices. SDS forms are available from your welding distributor or from the manufacturer.
- Also see [FOR ENGINE POWERED EQUIPMENT](#)

WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION



- Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to “**Safety in Welding and Cutting**” (ANSI Standard Z49.1) and the operating information for the equipment being used.

- When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to ensure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been “cleaned”. For information, purchase “Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances”, **AWS F4.1** from the American Welding Society.
- Vent hollow castings or containers before heating, cutting or welding. They may explode.
- Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuff-less trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- **Read and follow NFPA 51B** “Standard for Fire Prevention During Welding, Cutting and Other Hot Work”, available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, MA 02269-0101.
- **DO NOT** use a welding power source for pipe thawing.

CYLINDER MAY EXPLODE IF DAMAGED



- Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.

- Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.

Cylinders should be located:

- Away from areas where they may be struck or subjected to physical damage.
- A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- Never allow the electrode, electrode holder or any other electrically “hot” parts to touch a cylinder.
- Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, “Precautions for Safe Handling of Compressed Gases in Cylinders,” available from the Compressed Gas Association, 14501 George Carter Way Chantilly, VA 20151.

FOR ELECTRICALLY POWERED EQUIPMENT



- Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer’s recommendations.
- Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer’s recommendations.

BATTERY HANDLING, STORAGE, AND DISPOSAL



Batteries can be flammable substances such as lithium or other organic solvents, which may result in overheating, rupture, or combustion. Failure to follow the battery manufactures instructions may result in fire, personal injury, and damage to property if used improperly.

SAFETY INFORMATION

- DO NOT short circuit, disassemble, deform, or heat batteries.
- DO NOT attempt to recharge batteries unless they are specifically marked as "rechargeable".
- DO NOT use or charge the battery if it appears to be leaking, deformed or damaged in any way.
- Store in a cool location. Keep batteries away from direct sunlight, high temperature, and high humidity.
- Immediately discontinue use of the battery if, while using, charging, or storing the battery, the battery emits an unusual smell, feels hot, changes color, changes shape, or appears abnormal in any other way.
- Keep batteries out of reach of children, should a child swallow a battery, consult a physician immediately.
- Recycle or dispose of batteries in accordance with local and federal laws.

FOR LASER EMITTING EQUIPMENT



- Hazardous Class 4 (IV) laser products emit invisible, infrared laser radiation which can permanently damage the eye's retina and/or cornea, burn skin, and pose a fire risk. End users shall assign a qualified Laser Safety Officer (LSO) who has the certifications required by applicable law/standards, have a documented Laser Safety Program and have a Laser Controlled Area (LCA) that confirms to ANSI Z136.1 & Z136.9.
- Do not operate laser before end user's LSO has completed a risk assessment and all the prescribed Risk Mitigations measures have been fully implemented. Ensure the laser is operated/ demonstrated safely by trained personnel and that the environment surrounding the laser welding cell or laser-controlled area is safe for people nearby when the laser is in operation.
- Never point the laser at yourself or others. Never look directly into a laser aperture, even if wearing full eye protection.

- All persons inside LCA must wear proper PPE to avoid eye or skin exposure to laser radiation. The end user's LSO shall select proper PPE including, but not limited to, heat-resistant gloves, flame-resistant clothing, laser safety eye wear and laser-safe helmets that conform to ANSI Z136.1 Optical Density requirements for the wavelength and output power of the laser in use. Standard safety glasses and welding helmets DO NOT provide adequate protection from laser beam hazards. Always inspect PPE for damage or improper fit before use.
- Only qualified persons shall install, operate or service this unit per ANSI Z136.1 standards and your LSO's instruction. Read and follow all labels and manuals before installing, operating, or servicing hand held any laser welding equipment.
- Do not operate outside of a LCA, or if the laser protective housing is modified or damaged, or if safety interlocks have been bypassed or otherwise defeated. Inspect all equipment and LCA for damage or tampering prior to use.
- Reflected beams from the laser can damage eyes and skin and can pose a fire risk. Prior to use, the LCA should be assessed by the LSO to understand the surfaces where hazardous reflected beams can exist. Never position yourself or flammable material in the anticipated laser beam path and take extra precautions when working on reflective materials like aluminum and stainless steel.
- Follow all standards, individual facility or building regulations, and national, state, and local codes.

DEALER LOCATOR & PRODUCT REGISTRATION



Register your machine:

<https://www.lincolnelectric.com/register>

Authorized Service and Distributor Locator:

<https://www.lincolnelectric.com/locator>

ADDITIONAL SAFETY INFORMATION

Refer to <http://www.lincolnelectric.com/safety> for additional safety information

INSTALLATION

GENERAL DESCRIPTION

The FLEXCUT PRO FLEXCONNECT plasma arc cutting torches provide superior and reliable starting characteristics, cutting visibility and arc stability. The control system has a safety mechanism to insure that the nozzle and electrode are in place before cutting or gouging. The FLEXCUT PRO FLEXCONNECT torch handle design allows for an easy and ergonomic grip and operation. Consumables designed and patented to be used with FLEXCUT PRO FLEXCONNECT torches provide reliability and long life performance.

FLEXCUT PRO FLEXCONNECT plasma cutting torches provide all the features of the FLEXCUT® PRO offers while also offering the ability to flexibly change the torch head to a variety of different torch heads, such as 75 degree, 15 degree, Mechanized, and Extended Reach, without the need for an entire new torch assembly.

TECHNICAL SPECIFICATIONS

K#		KP5850-25 & KP5850-50	KP5852-25 & KP5852-50
Current Range		30 to 125 Amps	30 to 125 Amps
Duty Cycle		125 Amps at 60% 105 Amps at 100%	125 Amps at 100%
Gas Compatibility		Air & Nitrogen	Air & Nitrogen
Gas Pressure	Cutting	72-87 PSI (5.0-6.0 bar)	72-87 PSI (5.0-6.0 bar)
Gas Pressure	Gouging	50-65 PSI (3.5-4.5 bar)	50-65 PSI (3.5-4.5 bar)
Gas Flow at 105 A		610 SCFH (285 LPM)	630 SCFH (295 LPM)
Recommended Post Flow Time		30 sec	30 sec
Pilot Arc		Electrode to Tip (15-22 A)	Electrode to Tip (15-22 A)
Ignition		No HF	No HF
Certification Marks		IEC 60974-7	IEC 60974-7
Torch Cable Length		25' or 50'	25' or 50'
Operating Temperature		14°F to 104°F (-10°C to +40°C)	14°F to 104°F (-10°C to +40°C)
Storage Temperature		-13°F to +131°F (-25°C to +55°C)	-13°F to +131°F (-25°C to +55°C)

SELECT PROPER SETUP

A source of clean, dry air or nitrogen must be supplied to the FLEXCUT PRO FLEXCONNECT torch. Oil in the air is a severe problem and must be avoided. The supply pressure into the torch must be between 43 to 87 psi. Failure to observe these precautions could result in excessive operating temperatures or damage to the torch.

ENVIRONMENTAL LIMITATIONS

Locate the plasma cutter and FLEXCUT PRO FLEXCONNECT torch in a dry location with free circulation of clean air. Select a location to minimize the amount of smoke and dirt. The best practice is to keep the machine and torch in a dry, sheltered area.

OUTPUT CONNECTIONS

WARNING



ELECTRIC SHOCK CAN KILL.

Only personnel should install this torch.

Turn the input power OFF at the disconnect switch or fuse box and discharge input capacitors before working inside the equipment.

Do not touch electrically hot parts.

Turn the Power Switch OFF when connecting torch to power source

The FLEXCUT PRO FLEXCONNECT torch is sent from the factory inspected to Lincoln Electric product standards. If the torch is wet and/or dusty it may be necessary to clean the torch to expose the bare metal to make a good electrical connection with the consumables.

OPERATION

PREHEAT

WARNING



ELECTRIC SHOCK CAN KILL

Do not touch electrically live parts or electrode with skin or wet clothing.
Insulate yourself from work and ground.
Always wear dry insulating gloves.

WARNING



FUMES AND GASES CAN BE DANGEROUS

Keep your head out of fumes.
Use ventilation or exhaust to remove fumes from breathing zone.

WARNING



WELDING, CUTTING AND GOUGING SPARKS CAN CAUSE FIRE OR EXPLOSION

Keep flammable materials away.
Do not weld, cut or gouge on containers that have held combustibles.

WARNING



ARC RAYS CAN BURN

Wear eye, ear and body protection.

WARNING



PLASMA ARC CAN INJURE

Keep your body away from nozzle and plasma arc.
Operate the pilot arc with caution. The pilot arc is capable of burning the operator, others or even piercing safety clothing.

Observe additional Safety Guidelines detailed in the beginning of this manual.

PREHEAT TEMPERATURE FOR PLASMA CUTTING

Preheat temperature control is not necessary in most applications when plasma arc cutting or gouging. Preheat temperature control may be necessary on high carbon alloy steels and heat treated aluminum for

OPERATION

crack resistance and hardness control. Job conditions, prevailing codes, alloy level, and other considerations may also require preheat temperature control. The following minimum preheat temperature is recommended as a starting point. Higher temperatures may be used as required by the job conditions and/or prevailing codes. If cracking or excessive hardness occurs on the cut face, higher preheat temperature may be required. The recommended minimum preheat temperature for plate thickness up to 1/2" (12.7mm) is 70°F (21.1°C).

USER RESPONSIBILITY

Because design, fabrication, erection and cutting variables affect the results obtained in applying this type of information, the serviceability of a product or structure is the responsibility of the user. Variation such as plate chemistry, plate surface condition (oil, scale), plate thickness, preheat, quench, gas type, gas flow rate and equipment may produce results different than those expected. Some adjustments to procedures may be necessary to compensate for unique individual conditions. Test all procedures duplicating actual conditions.

DESIGN FEATURES AND ADVANTAGES

The FLEXCUT PRO FLEXCONNECT torch design makes plasma cutting easy. This list of design features and advantages will help you understand the torch's total capabilities so that you can get maximum use from your torch.

- Lightweight and ergonomic design for industrial use
- Rated for use up to 125 Amps
- Reliable touch start mechanism for plasma arc initiation
- Proprietary electrode, nozzle, and shield cap for optimum cooling, cut quality and long life

LIMITATIONS

Do not exceed output current and duty cycle rating of machine. Do not use the FLEXCUT PRO FLEXCONNECT torch for pipe thawing.


CONTROLS AND SETTINGS

Hand Held Torch

1. **Safety Switch:** Must be lifted and engaged prior to pressing the trigger for plasma cutting operation.
2. **Trigger:** Ignites the plasma arc and allow for arc transfer when it is engaged.




1. **Torch Connection:** Connect handheld or machine torch by inserting the FLEXCUT® PRO torch machine end connector into the power source terminal and turning the screw cap on the connector clockwise. Tighten the cap firmly by hand.
2. **Work Connection:** Connect cable with work clamp by inserting the connector and twisting to lock into place. Tighten firmly by hand.




TORCH HEAD REPLACEMENT AND OPTIONS


FLEXCUT PRO FLEXCONNECT torch system allows users to switch torch heads in seconds with no tools required. To change the torch head, simply grab the head of the torch and rotate the locking collar counterclockwise. Once the threads are no longer engaged, pull to remove.




Locate the new torch head and insert it into the female connector handle. Rotate the torch head locking collar clockwise about the threads until it is hand tight.



See below for the various torch head options available for the FLEXCUT PRO FLEXCONNECT system.




KP5856-1 – FLEXCUT PRO FLEXCONNECT 15° Handheld Torch Head




KP5855-1 – FLEXCUT PRO FLEXCONNECT 75° Handheld Torch Head




KP5854-1 – FLEXCUT PRO FLEXCONNECT Miniature Mechanized Torch Head



KP5853-1 – FLEXCUT PRO FLEXCONNECT Mechanized Torch Head




KP5838-1 – FLEXCUT PRO FLEXCONNECT Extended Reach Torch Head



KP5920-1 – FlexcutFLEXCUT PRO FLEXCONNECT XL Extended Reach Torch Head

HAND CUTTING TORCH PART CONFIGURATIONS

Different handheld torch configurations are available depending on the application.



Always use genuine Lincoln Electric electrodes, nozzles, and expendable parts for the best performance.

HAND CUTTING PROCESS


The air plasma cutting process uses air or nitrogen as a cutting gas and to cool the torch.

When preparing to operate, make sure you have all materials needed to complete the job and have taken all safety precautions. Install the machine as instructed in this manual and remember to attach the work clamp to the work piece.

- With the machine switched OFF, prepare the torch with the consumables adequate to the desired process (CUTTING / GRID).
- Connect the Torch and the work cable to the machine.
- Turn ON the Power Switch on the back of the machine; the display on the front panel will illuminate. The unit is now ready to operate.
- Verify correct gas pressure using the pressure level on the internal regulator.

OPERATION

- Select the desired process using the Control Knob on the user interface.
- Set the desired cutting current using the Control Knob on the user interface.
- Pilot Arc
 - The air will flow for a preflow time of 2 seconds and the pilot arc will start. (Exceptions: after a thermal, the initial trigger will be ignored. This is a safety feature to prevent the pilot arc from firing unexpectedly. The other exception is if the machine is in postflow, then the preflow time is skipped and the pilot arc will start immediately.)
 - The pilot arc will run for 5.0 seconds and shut off unless the arc is brought in contact with the work and the arc is transferred. Avoid excessive pilot arc time by transferring the arc to the workpiece quickly. This will extend consumable life.
 - When the arc is brought within 1/8" - 1/4" from the work piece the arc will transfer, the current will ramp to the setting on the control panel, and the cut can last indefinitely (or until the duty cycle of the power source is exceeded).



- Pierce the work piece by slowly lowering the torch onto the metal at a 30° angle away from the operator. This will blow the dross away from the torch tip. Slowly rotate the torch to vertical position as the arc becomes deeper.
- Keep moving while cutting. Cut at a steady speed without pausing. Maintain the cutting speed so that the arc lag is 10° to 20° behind the travel direction.
- Use a 5° - 15° leading angle in the direction of the cut.
- Finish the cut to be made and release the trigger.
- If the dross is difficult to remove, reduce the cutting speed. High speed dross is more difficult to remove than low speed dross.
- The Post Flow time is 20 seconds.

GENERAL RECOMMENDATIONS

- Follow safety precautions as printed throughout this operating manual and on the machine.
- Where possible, start the cut from the edge of the work piece. (This helps in longevity of consumable life.)
- If piercing is required, slowly lower the torch at an angle of about 30° to blow the dross away from the torch tip and slowly rotate the torch to a vertical position as the arc becomes deeper. This process will blow a lot of molten metal and dross. Be careful! Blow the dross away from the torch, the operator and any flammable objects.
- The nozzle should not be dragged on the metal surface.

- Clean spatter and scale from the nozzle frequently.
- Avoid unnecessary pilot arc starts as this will reduce consumable life. The pilot arc should only be fired as a means to transfer the arc to the work piece.

WARNING



ELECTRIC SHOCK CAN KILL

Turn off machine at the disconnect switch on the rear of the machine before tightening, cleaning or replacing consumables.

- During operation, if an error code is shown on the display located on the front panel:
 - Turn OFF the machine. Allow torch to cool.
 - Check the assembly of the torch consumables. If they are not properly in place, error code will continue to be displayed on the machine. Make sure that the shield cup is hand tight. Do not use pliers or over tighten.
 - Check the conditions on the inside of the nozzle. If debris has collected, rub the inside of the nozzle to remove any oxide layer that may have built up.
 - Check the condition of the electrode. If the end has a crater like appearance, replace it along with the nozzle. The maximum wear depth of the electrode is approximately .060." A green and erratic arc will indicate definite electrode failure and the electrode should be replaced immediately.
 - Replace the nozzle when the orifice exit is eroded away or oval shaped.
 - After the problem is found, or if there is nothing apparently wrong, the machine may need to be reset by turning the power switch OFF and then ON again. (It is possible for electrical noise to trip the safety circuit on rare occasions. This should not be a regular occurrence.)
- If the machine does not reset or continues to trip, consult the power source manual.

GOUGING PROCESS

Gouging is a process used to remove material without cutting entirely through the workpiece. The FLEXCUT PRO FLEXCONNECT has the capability of performing plasma gouging with the proper consumables attached to the torch. In general, gouging consumables provide a wider plasma arc compared to a cutting arc. As the material melts, it is blown forward by the pressurized gas coming out of the torch. The dross will land on the surface of the workpiece and can easily be removed after the gouging process is complete.

Applications:

Removing weld imperfections – cracks, porosity, inclusions, etc.

Back gouging for welding preparation

Removal of temporary fit up methods – tack welds, bracketing, etc.

Technique:

Hold the torch at a 45° angle to the workpiece. Pull the torch trigger to start the gouging arc. As the material is removed move the torch forward to continue removing material. When the desired amount of material has been removed, release the torch trigger to stop the gouging process.

Typically, the larger the angle between the torch and the workpiece, the deeper and slower the gouging. As the torch angle is decreased, less material is removed and the travel speeds can be increased. Keeping the torch fixed while moving forward will remove a straight line of material. Using a side-to-side, weaving motion will remove a wider area of material. The output of the FLEXCUT PRO FLEXCONNECT can also be increased or decreased to control the amount of material being removed. Most users tend to maximize the output to remove the most material in a short amount of time.

General Recommendations

- Follow safety precautions as printed throughout this operating manual and on the machine.
- Where possible, start the cut from the edge of the work piece. (This helps in longevity of consumable life.)
- If piercing is required, slowly lower the torch at an angle of about 30° to blow the dross away from the torch tip and slowly rotate the torch to a vertical position as the arc becomes deeper. This process will blow a lot of molten metal and dross. Be careful! Blow the dross away from the torch, the operator and any flammable objects.
- The nozzle should not be dragged on the metal surface. A drag shield is provided to maintain a consistent torch height. Refer to Torch Parts Configurations in this Section.
- Clean spatter and scale from the nozzle frequently.
- Avoid unnecessary pilot arc starts as this will reduce consumable life. The pilot arc should only be fired as a means to transfer the arc to the work piece.

WARNING



ELECTRIC SHOCK CAN KILL

Turn off machine at the disconnect switch on the rear of the machine before tightening, cleaning or replacing consumables.

- During operation, if an error code is shown on the display located on the front panel:
 - Turn OFF the machine. Allow torch to cool.
 - Check the assembly of the torch consumables. If they are not properly in place, error code will continue to be displayed on the machine. Make sure that the shield cup is hand tight. Do not use pliers or over tighten.
 - Check the conditions on the inside of the nozzle. If debris has collected, rub the inside of the nozzle to remove any oxide layer that may have built up.
 - Check the condition of the electrode. If the end has a crater like appearance, replace it along with the nozzle. The maximum wear depth of the electrode is approximately .060" (1.5mm). A green and erratic arc will indicate definite electrode failure and the electrode should be replaced immediately.
 - Replace the nozzle when the orifice exit is eroded away or oval shaped.
 - After the problem is found, or if there is nothing apparently wrong, the machine may need to be reset by turning the power switch OFF and then ON again. (It is possible for electrical noise to trip the safety circuit on rare occasions. This should not be a regular occurrence.)
- If the machine does not reset or continues to trip, consult the Troubleshooting Section.

MECHANIZED CUTTING

Mechanized Torch Installation


It is recommended that the FLEXCUT Pro mechanized torch be installed on a positioner with an arc voltage control capable of maintaining the cutting arc voltage within 1 volt. The positioner must be rigid to ensure cut quality and a torch collision sensor is highly recommended.

Installing the Mechanized Torch Consumables

To install torch parts, perform the following steps:

Note: Do not over tighten the consumables! Only tighten until the parts are seated properly.

1. Inspect the threads on the torch body and retaining cap and clean as necessary.
2. Install the electrode (2) into the torch body and press into place.
3. Thread the shield cap (6) onto the retaining cap assembly (5).
4. Insert the swirl ring (3) into the nozzle (4).
5. Place the swirl ring / nozzle assembly into the retaining cap.
6. Thread and tighten the retaining cap assembly onto the torch body (1).



Removing the Mechanized Torch Consumables

To remove torch parts, perform the following steps:

Removing the Torch Consumables

1. Remove the retaining cap from the torch.
2. Remove the swirl ring and nozzle from the retaining cap.
3. Separate the shield cap from retaining cap.
4. Remove the electrode from the torch body.
5. Remove the swirl ring from the nozzle.

⚠ WARNING



Contaminants such as dirt, metallic dust, oil and moisture present on the surface of the electrode and/or torch body can cause electrical arcing between these components and ultimately result in failure of the torch and consumables. In order to avoid damaging the torch and/or consumables, adhere to the following guidelines:


Ensure that the air supplied to the torch does not contain contaminants such as debris, moisture and oil.

Ensure that the torch cathode body and electrode body are clean prior to assembling the consumables into the torch. Wipe away any contaminants with a dry, lint free cloth.

Be sure that the consumables are properly tightened when installing them into the torch to ensure that there is no gap between the electrode body and cathode body. Check the installation of the consumables before the start of each work shift and frequently during each work shift to ensure that the parts have not become loose as a result of normal operation.

Inspect the surfaces of the cathode body and electrode body to ensure no contaminants have collected during operation. (Reference Figure Below)

OPERATION



Making a Cut

Use the following procedure to make a cut with the FLEXCUT PRO FLEXCONNECT.

1. Using the charts, determine the proper torch parts and cutting conditions for the material being cut.
2. Install the proper consumables into the torch.
3. Turn the power switch to the ON position to apply power to the FLEXCUT PRO FLEXCONNECT. The display on the front panel should illuminate.
4. Turn the Control Knob on the user interface to the maximum output current. Press the Control Knob, select the Air Pressure setting and adjust the pressure to 80 psi (5.5bar) for 25' (7.62m) torches and 85 psi (5.86bar) for 50' (15.24m) torches while gas is flowing through the torch. Return the knob to the correct current setting per the cut chart.
5. Use the Control Knob to adjust the Operating Process to CUTTING, as previously described in the Controls & Settings section.
6. The cutting operation is initiated after a start signal is received from the CNC. The arc should establish approximately 2 seconds after application of the start command. Throughout the cut, the display on the front panel should display cutting voltage in place of the Gas Purge and Advanced Settings are on the user interface. The cutting operation is terminated when the start signal is removed. At the completion of a cut, gas flow through the torch will continue for approximately 30 seconds, depending on the cutting current.

CONSUMABLE LIFE
 WARNING
**ELECTRIC SHOCK CAN KILL**

Turn off machine at the disconnect switch on the rear of the machine before tightening, cleaning, or replacing consumables.

Use the following guidelines to maximize consumable parts:

1. The FLEXCUT PRO FLEXCONNECT torch utilizes the latest advancement in technology for extending the life of the torch consumable parts. To maximize the life of the consumable parts, it is imperative that the shutdown procedure of the arc is carried out properly. The arc must be extinguished while it is still attached to the workpiece. A popping noise may be heard if the arc extinguishes abnormally. Note that holes are usually programmed without lead-outs to prevent loss of the arc during shutdown.
2. Use the recommended pierce height given in the cutting charts. A pierce height that is too low will allow molten metal that is ejected during the piercing process to damage the shield cap and nozzle. A pierce height that is too high will cause the pilot arc time to be excessively long and will cause nozzle damage.
3. Minimize firing the torch in the air. Nozzle damage will occur.
4. Make sure the torch does not touch the plate while cutting. Shield cap and nozzle damage will result.
5. Use a chain cut when possible. Starting and stopping the torch is more detrimental to the consumables than making a continuous cut.
6. Occasionally an oxide layer may form over the tip of the electrode, creating an insulating barrier between the electrode and nozzle. This will result in false starts. When this happens turn the power off, remove the shield cup and nozzle. Rub the inside surface of the nozzle, this will help remove any oxide buildup. Also, clean any oxide build up from the electrode. Replace the shield cup and nozzle, turn on the power and continue cutting. If false starts continue to occur after cleaning the consumables, then replace them with a new set. Do not continue to try and cut with excessively worn consumables as this can cause damage to the torch head and will degrade cut quality. Do not allow torch cable or body to contact hot surfaces.
7. Use only Lincoln consumable parts. These parts are patented and using any other replacement consumables may cause damage to the torch or reduce cut quality.
8. Make sure the air supply is clean and free of oil. Use several extra in line filters if necessary.
9. Minimize dross buildup on the nozzle tip by starting the cut from the edge of the plate when possible.
10. Pierce cutting should be done only when necessary. If piercing, angle torch about 30° from the plane perpendicular to the work piece, transfer the arc, then bring the torch perpendicular to the work and begin parallel movement.
11. Reduce the number of pilot arc starts without and/or before transferring to the work.
12. Set air pressure to recommended setting. A higher or lower pressure will cause turbulence in the plasma arc, eroding the orifice of the nozzle tip.

CUTTING CAPABILITY

The FLEXCUT PRO FLEXCONNECT handheld torch is rated at 125 amps, at 60% duty cycle on a 10 minute basis.

The FLEXCUT PRO FLEXCONNECT mechanized torch is rated at 125 amps, at 100% duty cycle on a 10 minute basis.

ACCESSORIES AND OPTIONS

ACCESSORIES AND OPTIONS

CONSUMABLE PROCESS KITS		
Part No.	Description	QTY
KP5829-35	Flexcut Pro Drag Cutting Kit - 35 A	1
KP5829-45	Flexcut Pro Drag Cutting Kit - 45 A	1
KP5829-65	Flexcut Pro Drag Cutting Kit - 65 A	1
KP5829-85	Flexcut Pro Drag Cutting Kit - 85 A	1
KP5829-105	Flexcut Pro Drag Cutting Kit - 105 A	1
KP5829-125	Flexcut Pro Drag Cutting Kit - 125 A	1
KP5830-45	Flexcut Pro Mechanized Cutting Kit - 45 A	1
KP5830-65	Flexcut Pro Mechanized Cutting Kit - 65 A	1
KP5830-85	Flexcut Pro Mechanized Cutting Kit - 85 A	1
KP5830-105	Flexcut Pro Mechanized Cutting Kit - 105 A	1
KP5830-125	Flexcut Pro Mechanized Cutting Kit - 125 A	1
KP5831-85	Flexcut Pro Gouging Kit - 45-85 A	1
KP5831-105	Flexcut Pro Gouging Kit - 105 A	1
KP5831-125	Flexcut Pro Gouging Kit - 125 A	1
KP5832-65	Flexcut Pro Extended Cutting Kit - 45-65 A	1
KP5832-85	Flexcut Pro Extended Cutting Kit - 85 A	1
KP5832-105	Flexcut Pro Extended Cutting Kit - 105 A	1
KP5832-125	Flexcut Pro Extended Cutting Kit - 125 A	1
KP5833-45	Flexcut Pro Precision Cutting Kit - 45 A	1
KP5834-45	Flexcut Pro Marking Kit - 45 A	1
KP5835-70	Flexcut Pro Level Cut Kit - 40-70 A	1
KP5835-125	Flexcut Pro Level Cut Kit - 80-125 A	1
K6115-25	Flexcut 25 FT [7.5 m] Control Cable	1
K6144-25	Flexcut 25 FT [7.5 m] Arc Start Switch Assembly	1

INDIVIDUAL CONSUMABLES		
Part No.	Description	QTY
KP5857-1	Flexcut Pro Electrode	5
KP5857-B25	Flexcut Pro Electrode, 25/pack	25
KP5858-1	Flexcut Pro Extended Electrode	5
KP5859-1	Flexcut Pro Level Cut Electrode (40-70 A)	5
KP5861-1	Flexcut Pro Cutting Nozzle (35 A)	10
KP5861-B25	Flexcut Pro Cutting Nozzle (35 A), 25/pack	25
KP5863-1	Flexcut Pro Cutting Nozzle (45 A)	10
KP5863-B25	Flexcut Pro Cutting Nozzle (45 A), 25/pack	25
KP5864-1	Flexcut Pro Cutting Nozzle (65 A)	10
KP5864-B25	Flexcut Pro Cutting Nozzle (65 A), 25/pack	25
KP5865-1	Flexcut Pro Cutting Nozzle (85 A)	10
KP5865-B25	Flexcut Pro Cutting Nozzle (85 A), 25/pack	25
KP5866-1	Flexcut Pro Cutting Nozzle (105 A)	10
KP5866-B25	Flexcut Pro Cutting Nozzle (105 A), 25/pack	25
KP5867-1	Flexcut Pro Cutting Nozzle (125 A)	10

INDIVIDUAL CONSUMABLES		
Part No.	Description	QTY
KP5867-B25	Flexcut Pro Cutting Nozzle (125 A), 25/pack	25
KP5868-1	Flexcut Pro Precision Cut Nozzle	10
KP5869-1	Flexcut Pro Marking Nozzle	10
KP5870-1	Flexcut Pro Level Cut Nozzle (40-70 A)	5
KP5871-1	Flexcut Pro Level Cut Nozzle (80-125 A)	5
KP5872-1	Flexcut Pro Gouging Nozzle (45-85 A)	10
KP5874-1	Flexcut Pro Gouging Nozzle (105 A)	10
KP5875-1	Flexcut Pro Gouging Nozzle (125 A)	10
KP5877-1	Flexcut Pro Extended Cutting Nozzle (45-65 A)	5
KP5878-1	Flexcut Pro Extended Cutting Nozzle (85 A)	5
KP5879-1	Flexcut Pro Extended Cutting Nozzle (105 A)	5
KP5880-1	Flexcut Pro Extended Cutting Nozzle (125 A)	5
KP5881-1	Flexcut Pro Swirl Ring (35-85 A)	2
KP5882-1	Flexcut Pro Swirl Ring (65-125 A)	2
KP6058-1	Flexcut Pro Swirl Ring (105-125 A Mechanized)	2
KP5836-1	Flexcut Pro Precision Cut Swirl Ring (45 A)	2
KP5883-1	Flexcut Pro Level Cut Swirl Ring (40-70 A)	2
KP5884-1	Flexcut Pro Level Cut Swirl Ring (80-125 A)	2
KP5887-1	Flexcut Pro Shield Cup Body (35-125 A)	1
KP5888-1	Flexcut Pro Shield Cup Body, Ohmic (45-125 A)	1
KP5889-1	Flexcut Pro Drag Cutting Shield Cap (35-85 A)	3
KP5889-B10	Flexcut Pro Drag Cutting Shield Cap (35-85 A), 10/pack	10
KP5890-1	Flexcut Pro Drag Cutting Shield Cap (105-125 A)	3
KP5890-B10	Flexcut Pro Drag Cutting Shield Cap (105-125 A), 10/pack	10
KP5891-1	Flexcut Pro Mechanized Cutting Shield Cap (45-85 A)	3
KP5891-B10	Flexcut Pro Mechanized Cutting Shield Cap (45-85 A), 10/pack	10
KP5892-1	Flexcut Pro Mechanized Cutting Shield Cap (105-125 A)	3
KP5892-B10	Flexcut Pro Mechanized Cutting Shield Cap (105-125 A), 10/pack	10
KP5893-1	Flexcut Pro Gouging Shield Cap	3
KP5894-1	Flexcut Pro Extended Cutting Shield Cap (45-125 A)	3
KP5895-1	Flexcut Pro Precision Cut Deflector Shield Cap	3
KP5837-1	Flexcut Pro Marking Shield Cap	3
KP5897-1	Flexcut Pro Level Cut Retaining Cap	1
KP5898-1	Flexcut Pro Level Cut Retaining Ring	2

TORCH ACCESSORIES		
Part No.	Description	QTY
KP5849-25	Flexcut Pro Torch - 25 FT [7.5 m]	1
KP5849-50	Flexcut Pro Torch - 50 FT [15 m]	1
KP5850-25	Flexcut Pro FlexConnect Torch - 25 FT [7.5 m]	1
KP5850-50	Flexcut Pro FlexConnect Torch - 50 FT [15 m]	1
KP5852-25	Flexcut Pro Mechanized FlexConnect Torch - 25 FT [7.5 m]	1
KP5852-50	Flexcut Pro Mechanized FlexConnect Torch - 50 FT [15 m]	1
KP5839-25	Flexcut Pro FlexConnect Cable - 25 FT [7.5 m]	1
KP5839-50	Flexcut Pro FlexConnect Cable - 50 FT [15 m]	1
KP5840-25	Flexcut Pro FlexConnect Mechanized Cable - 25 FT [7.5 m]	1
KP5840-50	Flexcut Pro FlexConnect Mechanized Cable - 50 FT [15 m]	1

TORCH ACCESSORIES		
Part No.	Description	QTY
KP5853-1	Flexcut Pro FlexConnect Standard Mechanized Torch Head	1
KP5854-1	Flexcut Pro FlexConnect Miniature Mechanized Torch Head	1
KP5855-1	Flexcut Pro FlexConnect 75° Handheld Torch Head	1
KP5856-1	Flexcut Pro FlexConnect 15° Handheld Torch Head	1
KP5838-1	Flexcut Pro FlexConnect Extended Reach Torch Head	1
KP5920-1	Flexcut Pro XL FlexConnect Extended Reach Torch Head	1
KP5916-1	Flexcut Pro Circle Cutting Kit	1
KP5917-1	Flexcut Pro Straight & Angle Cutting Kit	1
KP5918-1	Flexcut Pro 10 FT [3 m] Mechanized Cable Extension	1
KP5919-1	Flexcut Pro Mechafin Torch Adapter	1
KP5926-1	Flexcut Pro Mechanized Torch Rack	1
KP5849-15	Flexcut Pro Torch - 15 FT [4.5 m]	1

MAINTENANCE

CUT QUALITY



Before best quality cutting condition can be achieved on a particular material type and thickness, the operator must have a thorough understanding of the cutting characteristics of the FLEXCUT PRO FLEXCONNECT torch. When the cut quality is not satisfactory, the cutting speed, torch height, or gas pressures may need to be adjusted in small increments until the proper cutting condition is obtained. The following guidelines should be useful in determining which cutting parameter to adjust.

Before making any parameter changes, verify that the torch is square to the work piece. Also, it is essential to have the correct torch parts in place to ensure that they are in good condition. Check the electrode for excessive wear and the nozzle and shield cap orifices for roundness. Also, check the parts for any dents or distortions. Irregularities in the torch parts can cause cut quality problems.

1. A positive cut angle (top dimension of piece smaller than the bottom dimension) usually occurs when the torch standoff distance is too high, when cutting too fast, or when excessive power is used to cut a given plate thickness.
2. A negative cut angle (top dimension of piece larger than the bottom dimension) usually occurs when the torch standoff distance is too low or when the cutting speed is too slow.
3. Top dross usually occurs when the torch standoff distance is too high.
4. Bottom dross usually occurs when the cutting speed is either too slow (slow-speed dross) or too fast (high-speed dross). Low-speed dross is easily removed, while high-speed dross usually requires grinding or chipping off. Bottom dross also occurs more frequently as the metal heats up. As more pieces are cut out of a particular plate, the more likely they are to form dross.
5. Note that different material compositions have an effect on dross formation.
6. If the material is not being completely severed, the likely causes are that the cutting current is too low, the travel speed is too high, the gas pressure is incorrect, the incorrect consumables are installed in the torch, or the consumables are worn.

Inspection of Consumable Parts

When the cut quality is not satisfactory, use the following guidelines for determining which consumable parts need to be changed. Inspect all parts for dirt or debris and clean as necessary.

PART		INSPECT FOR	CORRECTIVE ACTION
	Swirl Ring	Damage Clogged holes	Replace Swirl Ring Blow out with compressed air, replace Swirl Ring if clogs can't be removed
	Electrode	Pit depth Erosion or Arcing	Replace Electrode if center depth is greater than .060" (1.5 mm) . Replace Electrode
	Nozzle	Center hole out of round Erosion or Arcing	Replace Nozzle Replace Nozzle
	Retaining Cap	Center hole out of round Dents, Cracks	Replace Retaining Cap Replace Retaining Cap
	Shield Cap	Dents, Scratches	Replace Shield Cap

TROUBLESHOOTING

HOW TO USE TROUBLESHOOTING GUIDE

WARNING



Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

1. LOCATE PROBLEM (SYMPTOM)

Look under the column labeled “PROBLEM (SYMPTOMS)”. This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting.

2. POSSIBLE CAUSE

The second column labeled “POSSIBLE CAUSE” lists the obvious external possibilities that may contribute to the machine symptom.

3. RECOMMENDED COURSE OF ACTION

This column provides a course of action for the Possible Cause, generally it states to contact your local Lincoln Authorized Field Service Facility.

CAUTION



If you do not understand or are unable to perform the Recommended Course of Action safely, contact your local Lincoln Authorized Field Service Facility.

Observe all additional safety guidelines detailed throughout this manual.

TROUBLESHOOTING CHART

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT	RECOMMENDED COURSE OF ACTION
The machine powers up properly, but there is no response when the trigger is pulled	1. Use the control knob to turn on the Air Purge function. If air does not flow, then: • The main gas solenoid assembly/pressure sensor may be faulty. Check or replace. • Possible faulty Control board. 2. Remove the handles (or barrel) of the torch and examine all the connections. 3. Check for proper trigger switch operation. Replace the trigger switch or torch cable if defective. 4. Possible faulty Control board.	If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Lincoln Authorized Field Service Facility.
When the trigger is pulled air begins to flow, but there is no pilot arc after at least 3 seconds	1. Check the torch consumables to be sure they are not dirty or greasy, and are in good shape. Replace the consumables if necessary. 2. Make sure the air pressure is set correctly. 3. Make sure there are no kinks or restrictions for air flow in the torch cable. Replace cable as needed. 4. If a slight thump cannot be felt in the torch when the trigger is pulled, check for loose connection in the torch head. 5. Possible faulty Control board.	If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Lincoln Authorized Field Service Facility.
The air begins to flow and there is a very brief arc that snap out consistently with repeated trigger pulls	1. Check the torch consumables to be sure they are in tight, not dirty or greasy and in good shape. Replace if necessary. 2. Make sure the air pressure is set correctly. 3. Possible faulty Control board.	If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Lincoln Authorized Field Service Facility.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT	RECOMMENDED COURSE OF ACTION
The arc starts but sputters badly	1. Check the torch consumables to be sure they are in tight, not dirty or greasy and in good shape. Replace if necessary. 2. Check air supply for oil or a great deal of water. If there is oil or a great deal of water, the air must be filtered or the machine switched to nitrogen or bottled air. 3. Make sure the air pressure is set correctly.	If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Lincoln Authorized Field Service Facility.
Pilot arc starts will not transfer when brought near the work piece	1. Check work lead connection for clean, secure connection. 2. Plasma will only cut conductive material. Do not attempt to cut fiberglass, plastic, rubber, PVC or any other non-conductive material. 3. Make sure work piece is clean and dry. Remove any scale, rust or dross. 4. Check all connections to Control board. 5. Possible faulty Control board.	If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Lincoln Authorized Field Service Facility.

CUSTOMER ASSISTANCE POLICY

CUSTOMER ASSISTANCE POLICY

The business of Lincoln Electric is manufacturing and selling high quality welding equipment, automated welding systems, consumables, and cutting equipment. Our challenge is to meet the needs of our customers, who are experts in their fields, and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for information or technical information about their use of our products. Our employees respond to inquiries to the best of their ability based on information and specifications provided to them by the customers and the knowledge they may have concerning the application. Our employees, however, are not in a position to verify the information provided or to evaluate the engineering requirements for the particular weldment, or to provide engineering advice in relation to a specific situation or application. Accordingly, Lincoln Electric does not warrant or guarantee or assume any liability with respect to such information or communications. Moreover, the provision of such information or technical information does not create, expand, or alter any warranty on our products. Any express or implied warranty that might arise from the information or technical information, including any implied warranty of merchantability or any warranty of fitness for any customers' particular purpose or any other equivalent or similar warranty is specifically disclaimed.

Lincoln Electric is a responsive manufacturer, but the definition of specifications, and the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements.

WELD FUME CONTROL EQUIPMENT

The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.

PARTS LIST

Content/Details may be changed or updated without notice. For most current Instruction Manuals, go to PARTS.LINCOLNELECTRIC.COM.



ISO OERLIKON AG Schweisstechnik

CH-5737 Menziken AG – Tel. +41 (0)62 771 83 05

E-Mail info@iso-oerlikon.ch – www.iso-oerlikon.ch